

CONNETTORI - BASI - CALOTTE PLUGS & SOCKETS - BASES - HOUSINGS INSERTS - EMBASES - BOITIER

CODE **S06**



PRESA 6 POLI 16 AMP
SOCKET 6 POLES 16 AMP
PRISE 6 POLES 16 AMP

CODE **P06**



SPINA 6 POLI 16 AMP
PLUG 6 POLES 16 AMP
FICHE 6 POLES 16 AMP

CODE **H06**



CALOTTA 6 POLI 16 AMP
HOUSING 6 POLES 16 AMP
BOITIER 6 POLES 16 AMP

CODE **B06**



BASE 6 POLI 16 AMP
BASE 6 POLES 16 AMP
EMBASE 6 POLES 16 AMP

CODE **S10**



PRESA 10 POLI 16 AMP
SOCKET 10 POLES 16 AMP
PRISE 10 POLES 16 AMP

CODE **P10**



SPINA 10 POLI 16 AMP
PLUG 10 POLES 16 AMP
FICHE 10 POLES 16 AMP

CODE **H10**



CALOTTA 10 POLI 16 AMP
HOUSING 10 POLES 16 AMP
BOITIER 10 POLES 16 AMP

CODE **B10**



BASE 10 POLI 16 AMP
BASE 10 POLES 16 AMP
EMBASE 10 POLES 16 AMP

CODE **S16**



PRESA 16 POLI 16 AMP
SOCKET 16 POLES 16 AMP
PRISE 16 POLES 16 AMP

CODE **P16**



SPINA 16 POLI 16 AMP
PLUG 16 POLES 16 AMP
FICHE 16 POLES 16 AMP

CODE **H16**



CALOTTA 16 POLI 16 AMP
HOUSING 16 POLES 16 AMP
BOITIER 16 POLES 16 AMP

CODE **B16**



BASE 16 POLI 16 AMP
BASE 16 POLES 16 AMP
EMBASE 16 POLES 16 AMP

CODE **S24**



PRESA 24 POLI 16 AMP
SOCKET 24 POLES 16 AMP
PRISE 24 POLES 16 AMP

CODE **P24**



SPINA 24 POLI 16 AMP
PLUG 24 POLES 16 AMP
FICHE 24 POLES 16 AMP

CODE **H24**



CALOTTA 24 POLI 16 AMP
HOUSING 24 POLES 16 AMP
BOITIER 24 POLES 16 AMP

CODE **B24**



BASE 24 POLI 16 AMP
BASE 24 POLES 16 AMP
EMBASE 24 POLES 16 AMP

SPINE DI ALIMENTAZIONE
SUPPLY VOLTAGE PLUGS
FICHES D'ALIMENTATION

CODE **SVP16-2**



SPINA 2P+T 16A 230V
PLUG 2P+T 16A 230V
FICHE 2P+T 16A 230V

CODE **SVP16-3**



SPINA 4P+T 16A 380V
PLUG 4P+T 16A 380V
FICHE 4P+T 16A 380V

CODE **SVP32-3**




SPINA 4P+T 32A 380V
PLUG 4P+T 32A 380V
FICHE 4P+T 32A 380V

EXAMPLES OF INSTALLATION
EXEMPLES D'INSTALLATION



SUPPLY VOLTAGE PLUG INSTALLED
FICHE D'ALIMENTATION INSTALLE'



24 POLES CONNECTORS INSTALLED
CONNECTEURS A 24 POLES INSTALLE'